

NEOACARE-TREATED LINOLEUM FLOORS TREATING DAMAGED AREA

MARMORETTE & LCH / ARABESQUE / COLORETTE / UNI WALTON / LINO ART / LINOECO



Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips



Single disk machine



Spray Cleaner



Red disk

| | | Equipment used | Cleaning products | Cleaning methods |
|-------|----------------------|----------------|-----------------------------|--|
| Floor | Removing of the dust | | - | • Damp sweeping |
| Floor | treatment | | Special spray for treatment | Manual spray cleaner vaporization on damaged area. Spread out the product with a wet mop. Mechanical washing at 160-200 rpm. Max 5 min/m² with red disk Leave the floor dry before use |

For daily and deep cleaning, please refer to the Gerflor protocol.